

### 型式表示方法



#### ① 吸盘连接规格

安装形式	固定式	嵌入式	螺纹式			
代码	H3	T8	M4	M6	M10	M20
适用吸盘规格	P1R P2R P3R P4R	P6R P8R P6B P8B P8P P10P P15P P20P	P10R P15R P10B P15B P10K P10W	P20R P25R P30R P40R P50R P20B P25B P30B P40B P50B P20K P30K P40K P50K P20W P30W P40W P50W	P60R P80R P100R P80B P70S P100S	P150R P200R

注：螺纹式连接处也可适配对应螺纹规格的吸盘 + 螺钉组合。

#### ② 缓冲行程

代码	行程	H3	T8	M4	M6	M10	M20
3	3mm	●	●	—	—	—	—
6	6mm	—	—	●	●	—	—
10	10mm	●	●	●	●	●	—
15	15mm	●	●	●	●	—	—
20	20mm	●	●	●	●	—	●

#### ③ 真空接口

快插式接头	代码	说明	H3	T8	M4	M6	M10	M20
螺纹式接口	B5	M5X0.8	●	●	—	—	—	—
	B6	M6X1	—	—	●	●	—	—
	B01	G1/8	—	—	—	—	●	—
	B02	G1/4	—	—	—	—	—	●

注：搭配快插接头和笋型接头可根据螺纹式接头规格选择。

#### PC 弹簧式顶部真空端口

规格型号	总高 B	安装螺纹 M	安装调节高度 L	真空接口 D	行程 S	弹簧力度 N	吸盘连接处规格
PC-H3-3-B5	26.5	M12X1	13	M5X0.8	3	0.9~1.9	-H3
PC-H3-10-B5	40.5	M12X1	17.5	M5X0.8	10	0.6~1.7	-H3
PC-H3-15-B5	51.5	M12X1	23.5	M5X0.8	15	0.4~0.7	-H3
PC-H3-20-B5	61.5	M12X1	28.5	M5X0.8	20	0.3~1.8	-H3
PC-T8-3-B5	29	M12X1	13	M5X0.8	3	0.9~1.9	-T8
PC-T8-10-B5	40.5	M12X1	17.5	M5X0.8	10	0.8~2.7	-T8
PC-T8-15-B5	51.5	M12X1	23.5	M5X0.8	15	0.7~3.0	-T8
PC-T8-20-B5	61.5	M12X1	28.5	M5X0.8	20	0.9~3.4	-T8
PC-M4-6-B6	38	M14X1	20	M6X1	6	4~7.1	-M4
PC-M4-10-B6	42.5	M14X1	20	M6X1	10	2~5.2	-M4
PC-M4-15-B6	52.5	M14X1	25	M6X1	15	2~5.9	-M4
PC-M4-20-B6	68.5	M14X1	34	M6X1	20	1.1~4.8	-M4
PC-M6-6-B6	38	M14X1	20	M6X1	6	7~12.6	-M6
PC-M6-10-B6	44	M14X1	20	M6X1	10	3.3~10	-M6
PC-M6-15-B6	54	M14X1	25	M6X1	15	3.3~10.4	-M6
PC-M6-20-B6	70	M14X1	34	M6X1	20	2~8.7	-M6
PC-M10-10-B01	56	M22X1	26	G1/8	10	10.1~15.8	-M10
PC-M20-20-B02	119	M30X2	48	G1/4	20	14~25.5	-M20

